


TWO- WAY WIRELESS SYSTEM INSTRUCTIONS

1. WIPE THE DEVICE AND HEADSET WITH A SANITIZING WIPE AND/OR SPRAY. PLACE A DISPOSABLE MICROPHONE COVER ON THE HEADSET:




2. TURN ON THE DEVICE BY PRESSING AND HOLDING THE POWER BUTTON UNTIL THE DISPLAY TURNS ON:




INSTRUCTIONS CONTINUED ON BACK

3. TO TOGGLE THE MICROPHONE FOR THE HEADSET, ON AND OFF, TAP THE TALK BUTTON:



4. TO ADJUST THE HEADSET VOLUME, PRESS THE BUTTONS ON THE LEFT SIDE. PRESS THE TOP BUTTON TO INCREASE VOLUME AND THE BOTTOM BUTTON TO DECREASE VOLUME.



5. WHEN DONE, TURN OFF THE DEVICE BY PRESSING AND HOLDING THE POWER BUTTON UNTIL THE DISPLAY TURNS OFF.
6. THROW AWAY THE MICROPHONE COVER AND WIPE THE DEVICE AND HEADSET WITH A SANITIZING WIPE AND/OR SPRAY.